



Work Instruction

Cleaning the inclined screw

Step	What do you have to do?	Photo
Always use the appropriate PPE (personal protective equipment)!		
1	Close the silo hatch.	
2	Run the inclined screw empty until no more material comes out.	
3	Disconnect the power supply from the control cabinet: <ul style="list-style-type: none">• Unplug the cable from the site power connection.• Turn the main switch off.	



4

Check whether the outlet of the inclined screw is clean and free of material.

If not, gently tap around the outlet with a hammer to loosen any remaining residue.

